

SUPERVISION AND PROTECTION ASSEMBLY (P/N 10-2360)

Important Notices

1. Please read the instructions carefully! Fike products are used for the protection of life and critical assets if installed and tested as described in this document.
2. Do not use Fike products for any application for which it is not intended. Fike shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Fike product for which the product is not intended by Fike.
3. Do not use Fike products described in this document outside of the ranges specified by Fike. Fike shall have no liability for malfunctions or damages arising out of the use of Fike products beyond such specified ranges.
4. Fike reserves the right to change product designs or specifications without obligation and without further notice.
5. This document is subject to Fike's full disclaimer at <http://www.fike.com/disclaimer>.
6. Visit www.fike.com to contact us or to download the latest version of this document.

Specifications

Output Circuits:	Supervised, Power-limited 2 amps maximum, 24VDC
Dimensions	13.25" Long (377 mm)
Weight:	0.08 lbs. (36 grams)
Operating Temperature:	32°F to 120°F (0°C to 49°C)
Humidity:	93% RH, non-condensing
Wire Leads:	4, 18 Gauge x 4" (10.16 cm) ± long Solenoid: White (-) and Red (+) Module: Black (-) and Red (+)
Compatibility:	Refer to Fike document 06-186 for compatible solenoids.

Module Programming

Each control panel uses software to configure the Supervised Control Module and Release Control Module. The Supervised Control Module MUST be configured for non-silenceable, not active for Drill, and the appropriate activation state (usually ALARM). The Release Control Module is configured for the type of solenoid operation required and the required output state.

Installation Instructions


- 1) If the system is already powered, disable critical functions and power down system.

⚠ CAUTION
The addressable module circuit board contains static sensitive components. Handle the electronics by the edges only and avoid touching the integrated components. Always ground yourself with a proper wrist strap before handling the module(s). If the installer is properly grounded at all times, damage due to static discharge will not occur.


- 2) Disconnect the solenoid or UVO from the suppression system valve.
- 3) Connect the EMF Protection assembly to the solenoid or UVO and to the control module as shown in the diagrams on the next page. Locate the 10-2360 assembly as close to the solenoid or UVO as possible.

⚠ CAUTION
When installing the EMF Protection assembly, it is extremely important that close attention be given to correct wiring polarity to prevent potential damage to the control module and potentially the system control panel itself.

- 4) Power up the control panel and test solenoid or UVO for proper operation.
- 5) Reset the releasing panel to return the solenoid or UVO to normal (deactivated) operation.
- 6) Reconnect the solenoid or UVO to the suppression system valve only after proper operation has been verified.



Supervised Control Module Connection to Solenoid



Releasing Control Module Connection to Solenoid or UVO

⚠ CAUTION

Attaching a solenoid directly to the addressable module without the EMF Protection Assembly installed can result in irreparable damage to the module and the system control panel as well.