

PROINERT®2 DISCHARGE HOSE ASSEMBLY



Description

The flexible discharge hose assembly provides the connection between the cylinder valve outlet and the discharge manifold. The hose assembly includes a discharge hose and check valve. When installed properly, the check valve provides a means of preventing back-flow of agent through a disconnected discharge hose in the event of an accidental discharge during installation or while a cylinder is removed for service.

NPT and BSP options are available.

Specifications

Working Pressure	5,076 psi (350 bar) maximum
Material	Hose – synthetic rubber with zinc-plated steel connectors Check Valve – brass
Overall Length	22.0" (560 mm)
Minimum Bend Radius	9.8" (250 mm)

Ordering Information

The discharge hose is included in the discharge valve completer kits or it may be ordered separately using the following part numbers.

Part Number	Description
IG71-123	Discharge Hose, 1 inch NPT
IG71-003	Discharge Hose, 1 inch BSP

Approvals

Underwriters Laboratories (UL)
Underwriters Laboratories of Canada (ULC)
Factory Mutual (FM)

For exact certification listings, please reference the respective agency web site.

This document is only intended to be a guideline and is not applicable to all situations. Information is subject to Fike's full disclaimer at <http://www.fike.com/disclaimer>.