

## CONTAINER RECHARGE KITS FOR SYSTEMS USING 3M™ NOVEC™ 1230 FIRE PROTECTION FLUID

### Description

After a system has been discharged, the container's rupture disc valve must be rebuilt before the container can be recharged and placed back into service. The recharge kits contain all of the items required to rebuild the valve. Refer to Fike's Recharge Manual (P/N 06-852) for a detailed procedure on how to recharge a Fike Impulse Valve container.

1 IN (25mm) Recharge Kit, P/N 85-049		
<i>Used on 5, 10, 20, 35, 60 &amp; 100 lb. (2, 4, 8, 15, 27 &amp; 44 L) containers.</i>		
Item	Description	Part Number
1	Friction Ring	70-2060
2	Disc Assembly	70-352
3	O-Ring	02-11987
4	Valve Core-Fill Port (not shown)	02-4161
5	Reconditioning Instructions (not shown)	06-567

3 IN (80mm) Recharge Kit, P/N 85-050		
<i>Used on 150, 215, 375, 650 &amp; 1000 lb. (61, 88, 153, 267 &amp; 423 L) containers</i>		
Item	Description	Part Number
1	Friction Ring	70-2063
2	Disc Assembly	70-353
3	O-Ring	02-11989
4	Valve Core-Fill Port (not shown)	02-4161
5	Reconditioning Instructions (not shown)	06-567

### Valve Assembly



### Approvals

Underwriters Laboratories (UL)  
 Underwriters Laboratories of Canada (ULC)  
 Factory Mutual (FM)

*For exact certification listings, please reference the respective agency web site.*

This document is only intended to be a guideline and is not applicable to all situations. Information is subject to Fike's full disclaimer at <http://www.fike.com/disclaimer>.