



## INSTRUCTIONAL SIGNS FOR SYSTEMS USING 3M™ NOVEC™ 1230 FIRE PROTECTION FLUID

#### Description

Instructional signs are used to provide the necessary information to personnel in the area and to comply with NFPA 2001 requirements. The caution lettering and backgrounds meet the requirements of ANSI Z535. The signs are made from flame retardant, Lexan™ polycarbonate material. Each sign has an adhesive backing for mounting purposes. These signs are an optional item and must be ordered separately.

### **Approvals**

Underwriters Laboratories (UL)
Underwriters Laboratories of Canada (ULC)
Factory Mutual (FM)

For exact certification listings, please reference the respective agency web site.

# CAUTION - AREA PROTECTED Novec™ 1230 (P/N 02-17005)

The purpose of this sign is to inform personnel that the room they are entering is protected by an extinguishing system using 3M™ Novec™ 1230 fluid and that they should not enter the area during or after discharge. It also provides instructions that all doors serving the protected area must be kept closed at all times. This sign is to be mounted to the exterior of all doors entering the protected area.

Dimensions	13" (330 mm) wide x 10" (254 mm) high
Caution Text	Black lettering on yellow background
Body Text	Black lettering on white background



THIS AREA IS PROTECTED BY AN EXTINGUISHING SYSTEM USING 3M™ NOVEC™ 1230 FLUID

DO NOT ENTER AREA DURING OR AFTER DISCHARGE

**KEEP DOOR CLOSED AT ALL TIMES** 

## CAUTION – SYSTEM DISCHARGE ALARM (P/N 02-17006)

The purpose of this sign is to inform personnel that the room is protected by an extinguishing system using 3M™ Novec™ 1230 fluid and that they should not enter the protected area if the discharge notification appliance is active. This sign is to be mounted on the exterior of the protected area by each discharge notification appliance.

Dimensions	9" (229 mm) wide x 6" (154 mm) high
Caution Text	Black lettering on yellow background
Body Text	Black lettering on white background



EXTINGUISHING SYSTEM USING 3M™ NOVEC™ 1230 FLUID

IF ACTIVE DO NOT ENTER AREA

This document is only intended to be a guideline and is not applicable to all situations. Information is subject to Fike's full disclaimer at <a href="http://www.fike.com/disclaimer">http://www.fike.com/disclaimer</a>.

Form No. 26-1752-01 ISO 9001:2015 Certified Page 1 of 3

## **NOTICE – MANUAL ACTUATION SIGN (P/N 02-16306)**

The purpose of this sign is to inform personnel that the manual release button on the container cannot be used to activate the containe. Manual release switch(s) located at the hazard exit must be used to activate the system. This sign is to be mounted by each suppression system alarm notification appliance within the protected area.

Dimensions	13" (330 mm) wide x 10" (254 mm) high
Caution Text	White lettering on blue background
Body Text	Black lettering on white background

# NOTICE

THE RED MANUAL RELEASE BUTTON
ON THIS CONTAINER CANNOT BE
USED TO ACTIVATE THE
FIRE SUPPRESSION SYSTEM

USE THE MANUAL RELEASE SWITCH LOCATED AT THE EXIT TO ACTUATE THE SYSTEM

## CAUTION - EXIT AREA (P/N 02-17007)

The purpose of this sign is to inform personnel working within the protected area that if the notification appliance is active, the extinguishing system using 3M<sup>™</sup> Novec<sup>™</sup> 1230 fluid will soon be discharged and appropriate actions should be taken. This sign is to be mounted by each suppression system alarm notification appliance within the protected area.

Dimensions	9" (229 mm) wide x 6" (154 mm) high
Caution Text	Black lettering on yellow background
Body Text	Black lettering on white background



SYSTEM ALARM FOR EXTINGUISHING SYSTEM USING 3M™ NOVEC™ 1230 FLUID

IF ACTIVE EXIT AREA IMMEDIATELY

#### SYSTEM RELEASE SIGN (P/N 02-17008)

The purpose fo this sign is to inform personnel working within the protected area that this switch is used to manually activate the extinguishing system using 3M™ Novec™ 1230 fluid. This sign reduces the risk of a manual release station being mistaken for a fire alarm pull station. This sign is to be mounted by each manual release station within the protected area.

Dimensions	4" (102 mm) wide x 2.25" (57 mm) high
Text	Red lettering on white background

# **SYSTEM RELEASE**

EXTINGUISHING SYSTEM USING 3M™ NOVEC™ 1230

This document is only intended to be a guideline and is not applicable to all situations. Information is subject to Fike's full disclaimer at <a href="http://www.fike.com/disclaimer">http://www.fike.com/disclaimer</a>.

Page 2 of 3 ISO 9001:2015 Certified Form No. 26-1752-01

#### MAIN / RESERVE SIGN (P/N 02-17009)

Ths purpose of this sign is to inform personnel that this switch is used to select wether the main or reserve containers associated with the extinguishing system using  $3M^{\text{\tiny TM}}$  Novec<sup>TM</sup> 1230 fluid are connected to the releasing panel for area protection. This sign should be placed at each main/reserve switch location for positive identification.

Dimensions	4" (102 mm) wide x 2.25" (57 mm) high
Text	Red lettering on white background

## **SYSTEM RELEASE**

EXTINGUISHING SYSTEM USING 3M™ NOVEC™ 1230

## SYSTEM ABORT SIGN (P/N 02-17010)

The purpose of this sign is to inform personnel working within the protected area that this switch is used to abort (interupt) the activation of the extinguishing system using  $3M^{\text{\tiny TM}}$  Novec<sup>TM</sup> 1230 fluid. This sign is to be mounted by each abort switch within the protected area.

Dimensions	4" (102 mm) wide x 2.25" (57 mm) high
Text	Red lettering on white background

#### **SYSTEM ABORT**

## **PUSH AND HOLD**

EXTINGUISHING SYSTEM USING 3M™ NOVEC™ 1230

This document is only intended to be a guideline and is not applicable to all situations. Information is subject to Fike's full disclaimer at <a href="http://www.fike.com/disclaimer">http://www.fike.com/disclaimer</a>.

Form No. 26-1752-01 ISO 9001:2015 Certified Page 3 of 3